


**bauer**


**ВЕСЕЛЫЕ  
ГОРКИ**  
с кубиками

**ИНСТРУКЦИЯ**

Инструкция Нұсқаулық



**Арт - 1133**




1



2



3




4




5




6





7



8



2



1



1



1




1




2


9





10




11




12







13




14






19




20





21





22




23




24



25







2






3




7




1








30




31



32



33





5



1



4




6




5




34




35





36





37





38



40



41



42



1



2



2



1




1







1




1



43



44





1



2



2



1



2




8




1



46



47



48





2






1






1




1





49




50











**Предупреждение! Детям младшего возраста при сборке может понадобиться помощь взрослых.**



Официальный интернет-магазин  
[www.toysbauer.ru](http://www.toysbauer.ru)

Служба поддержки покупателей

  +7 (916) 005 46 88

Email [support@toysbauer.ru](mailto:support@toysbauer.ru)